

## Liquid Skin Highlighter - "Sophisticated Sparkle" Ref: SC/3144/EU

Skin Care

Product Name A	INCI Name	%W/W 100.00	Supplier
Water	Aqua	91.45	
PURABYK-R 5510	Bentonite (and) Xanthan Gum	1.30	www.byk.com
В			
DUB GMS	Glyceryl Stearate	2.00	www.stearinerie-dubois.com
DUB 50 P	Stearic Acid (and) Palmitic Acid	1.00	www.stearinerie-dubois.com
С			
Citric Acid (10%)	Citric Acid	q.s.	
MIRAGE Holo Magic	Calcium Sodium Borosilicate (and) Titanium Dioxide (and) Tin Oxide (and) Iron Oxides (and) Silica	3.00	www.eckart.net
SYNCRYSTAL Supernova Gold	Synthetic Fluorphlogopite (and) Titanium Dioxide (and) Iron Oxides (and) Tin Oxide	0.25	www.eckart.net
Deep Jungle Flower	Fragrance	0.20	www.bell-europe.com
Euxyl PE 9010	Phenoxyethanol, Ethylhexylglycerin	0.80	www.schuelke.com

## Procedure:

- 1. Disperse PURABYK-R 5510 in water with very high shear
- 2. Heat phase A and phase B separately to 80°C
- 3. Add phase B to phase A
- 5. Adjust pH to 6.5 with citric acid (10%)
- 6. Add the remaining ingredients of phase C step by step
- 7. Cool down to RT and fill into an appropriate container

- ⇒ SYNCRYSTAL Supernova Gold gives that golden color, while MIRAGE Holo Magic provides the skin with beautiful sparkling highlights
- ⇒ PURABYK-R 5510 improves the stability of the texture by thickening and stabilizing effects. The specific rheology behavior allows an excellent application



Stability:

Stable for at least 6 months at RT and 40°C. Stable for at least 1 month at 50°C.

Customer Support

ECKART GmbH ECKART Cosmetic Colours LLC ECKART Asia Limited info.eckart@altana.com info.eckart.cosmetics@altana.com info.eckart.asia@altana.com

Date: 13.02.2023 Revision: 13.02.2023

