



Let it Glow!

Hi!ighting Fluid - "It's Glow Time"

Skin Care

Ref: SC/3039/EU

Product Name	INCI Name	%W/W	Supplier
A			
Water	Aqua	q.s.	
OPTIGEL-CL XR	Magnesium Aluminum Silicate	1.20	www.eckart.net
B			
Tegin M Pellets	Glyceryl Stearate	2.00	www.evonik.com
DUB 50 P	Stearic Acid (and) Palmitic Acid	1.00	www.stearinerie-dubois.com
C			
Citric Acid (10%)	Citric Acid	q.s.	
MIRAGE Bright Silver	Calcium Sodium Borosilicate (and) Titanium Dioxide (and) Tin Oxide	5.00	www.eckart.net
MIRAGE Bright Red	Calcium Sodium Borosilicate (and) Titanium Dioxide (and) Tin Oxide	5.00	www.eckart.net
Precious	Fragrance	0.20	www.barentz.com
Euxyl PE 9010	Phenoxyethanol, Ethylhexylglycerin	0.80	www.schuelke.com

Procedure:

1. Disperse OPTIGEL-CL XR in water with very high shear
2. Heat phase A and phase B separately to 80°C
3. Add phase B to phase A
5. Adjust pH to 6.5 with citric acid (10%)
6. Add the remaining ingredients of phase C step by step

- ⇒ MIRAGE Bright Red and MIRAGE Bright Silver gives the skin a naturally luminous and dewy glow
- ⇒ OPTIGEL-CL XR improves the stability of the texture by thickening and stabilizing effects. The specific rheology behavior allows an excellent application



Stability:

Stable for at least 6 months at RT and 40°C.
Stable for at least 1 month at 50°C.

Customer Support

ECKART GmbH
info.eckart@altana.com

ECKART Cosmetic Colours LLC
info.eckart.cosmetics@altana.com

ECKART Asia Limited
info.eckart.asia@altana.com

Date: 13.11.2019
Revision : 13.11.2019